



Getting Started with your Kestrel Drop

Overview





Figure 1: Overview

Changing Settings



Factory Reset
Device Manual
Device Info





Battery Life

- The battery life will vary based on usage.
- For baseline conditions and settings*, the battery will last approximately 6 months.
 - *Temp = 24°C, Logging Rate = 10 Minutes, Update Rate = 30 seconds.
- Battery life will be reduced by:
 - Colder conditions
 - More frequent logging or update rates
- Downloads of large data logs (or firmware updates) are best completed with a fresh battery and in temperatures above 10°C / 50°F.

Battery Replacement



Figure 2: Battery Replacement

	Unit is on. (Only powers off if battery is removed)	
If Battery is Inserted	Bluetooth is on.	
-	Drop is logging data.	

LED Indicators

LED Condition	Status Button	Possible Conditions
Blinking Green Light	Pressed	Unit is functioning normally.
	Not Pressed	Battery was inserted.
		Bluetooth has connected successfully.
		Bluetooth has disconnected successfully.

Note: Status button can be used to immediately send a connection signal to your iOS device.

Please go to http://www.r-p-r.co.uk/kestrel-drops/drops.htm for more information.





Connecting to an iOS Device

- Please see: http://www.r-p-r.co.uk/downloads/kestrel-drop/Kestrel-Connect-Instructions.pdf
- All data logged by the Drop since your last connection will automatically download to your iOS device upon your next connection.

